

## **Technical Product Information**

132.00

Issue 11/2001

Reliable and accurate regulation,



### **Application**

- The RMG 132-A rotary displacement meter is designed for gas volume measurement in gas installations
- It can be used for all non-corrosive gases (e.g. natural gas; propane, butane gas, nitrogen, air etc.)
- · It can also be used for intermittent gas sampling

### **Function**

The rotary displacement meter consists of the measuring unit and the counter unit. The gas flowing in the measuring unit causes special rotors to turn. These let through an exactly specified volume of gas. These rotations are transferred to the non-pressurized counter unit via a magnet coupler, where

they are totalized and indicated on the index as a volumetric value. The counter unit is rotatable and can be adapted to the corresponding flow directions of the gas meter. The rotations of the rotors can also be further processed as electrical signals.

### **Testing / Calibration**

The rotary displacement meters comply with the requirements of the DVGW, PTB, EEC and other international and national regulations in different countries. The rotary displacement meter can be universally adapted to the flow direction without requiring the involvement of calibration authorities. Each rotary displacement meter is tested in its

operational state and certified in an authorized test center for gas measuring devices. The rotary displacement meters can also be tested and approved as a standard measure. The quality results of the leakage and tightness tests are documented in accordance with the international standards.

### **General features**

### General

Nominal pressure
 PN 16 : ANSI 150# Class

• Flow direction Universal

Approvals PTB, EEC, ofgem, other international

Design to DVGW VP 900

Degree of protection IP 65

Operating temperature -40°C to +60°C, -40 F to 140 F

Piston materialHousing materialAluminum alloyAluminum alloy

Installation
 No minimum runs of inlet or outlet line required

### Measuring unit

Measuring range
 Turndown: 1:50 (standard) to 1:160 (optional)

Measuring accuracy < 2% at  $Q_{min}$  to  $Q_t$  ( $Q_t = 0.1 x Q_{max}$  at 1:50)

< 1% at Qt to Qmax (factory set 0.5%)

Reproducibility  $< \pm 0.1\%$ 

Pressure loss max. 2.5 mbar, 1" wc at Q max

(standard natural gas density)

Overload For short periods up to 1.25 Q max and

pressure reduction speed of 0.5 bar/s, 7 PSI/sec

Measuring connections
 Pressure and temperature measuring connection

at the inlet and outlet of the meter housing

Impulse transmitters
 1x LF (Reed) standard, options for other LF and HF

Oil level indication
 On front (standard), at both ends optional

### Counter unit (mechanical)

Display
 8-digit direct read index reading ft<sup>3</sup>

Visual startup indication

Installation Universally adaptable to flow direction in the field

See "Flow Change" section of this manual




## **Design features**

### **Connection types**

Versions PN 16 (flange to DIN 2501)	ANSI 150 (flange to ANSI B16.5RF)
-------------------------------------	-----------------------------------

### **Connection types**

Size G	DN (inch)	A	В	С	D	L	Weight Lb	Flange with Threaded holes	
		I	1	Inche	S	I	I	DIN 2501	ANSI B16.5
132-2.3	<b>5</b> 0 (2")	13.75	9	4.75	7	6.75	29	4x M16	4x 5/8
132-3.5	<b>5</b> 0 (2")	13.75	9	4.75	7	6.75	29	4x M16	4x 5/8
132-5.6	<b>8</b> 0 (3")	16.5	10.5	6.125	7	6.75	36	8x M16	4x 5/8
132-8.8	<b>8</b> 0 (3")	20.75	12.625	8.125	8.25	9.5	51	8x M16	4x 5/8



- 1 Counter unit 2 Measuring unit
- 3 Pressure measuring connection
- 4 Temperature measuring connection
- 5 Impulse transmitter connection
- 6 Oil level indicator

### **Measuring features**

**Measuring ranges** (calibration with air at atm. pressure)

			Measuring ranges down to							
Size	DN (inch)	Q <sub>max</sub> ft³/h	1:20	1:50	1:65	1:80	1:100	1:160	LF Impulse	HF Impulse
			Q min					Imp./ft³	Imp./ft³	
			ft³/h						approx	
132-2.3	50 (2")	2300	110	45	35	28	-	-	10	6000
132-3.5	50 (2")	3500	175	70	55	45	35	-	10	6000
132-5.6	80 (3")	5600	280	105	90	70	55	45	1	3750
132-8.8	80 (3")	8800	460	175	140	105	85	55	1	2400

Note: Standard - Measuring range 1:50

### Impulse transmitters

LF - Reed contact; polarity-free


- Voltage U=5-24V DC

- Current max. I=10mA

HF - NAMUR; Observe polarity

- Voltage U=8 V DC

- Current active area free > 3mA; active area covered < 1 mA



Versions	2x LF	1x LF; 1x HF	2xLF; 1x HF	1x LF; 2x HF
----------	-------	--------------	-------------	--------------

Note: Standard - 1x LF Pin 1;4

### Thermowells for temperature measurement

Design according to connection type

PN 16 - Thermowells (2 possible at each inlet and outlet)

PN 16 versions	1x inlet	1x outlet	1x inlet and outlet	2x inlet	
----------------	----------	-----------	---------------------	----------	--

Note: Standard without thermowells Connections closed with M14 x 1.5 sealing screws

ANSI 150 - Thermowells (1 possible at each inlet and outlet)

ANSI 150 versions	1x inlet	1x outlet	1x inlet and outlet
-------------------	----------	-----------	---------------------

Note: Standard without thermowells, connections closed with 3/4 NPT sealing screws

### Pressure measuring connections


Design according to connection type

PN 16 - Coupling (M10x1) with locking cone for Ø 6mm pipe at inlet and outlet

ANSI 150 - 1/4 NPT sealing plug at inlet and outlet



## Flow change



### **Accessories**

- Startup filter
   Design according to connection type (DN 50, DN 80, DN 100)
   gas tight grooved dirt filter seal with mounting strap, mesh width 0.4 mm
- Corrector
- Three-way test valve
- · Fastening bracket for corrector
- Thermowell

Note: Thermowell, three-way test valve and fastening bracket as preparation for mounting a corrector on the rotary displacement meter.

### Installation and maintenance

Fit the de-energized meter with the appropriate standard seals and bolts in the pipelines. Ensure that the oil level window is at the bottom for both horizontal and vertical gas flow. Use a sieve or filter upstream of the meter when used with dirty pipelines or gases.

Fill the oil in the gear cover and check the oil level. Now open the gas supply slowly upstream of the meter. Check the tightness of the connection, e.g. leakage detection spray. After the check also open slowly the downstream valve.

Maintenance only requires the approx. yearly inspection of the oil level.

### **Ordering data**

### Composition of order designation

RMG 132-A - Size-DN-Pressure rating/Flange connection-Measuring range-Impulse transmitter-Thermowell

**Example:** RMG 132-A - G 65 - DN 50 - PN 16 - 1:80 - 1x LF - 2x (input)

Size
Diameter nominal
Pressure rating/
Flange connection

G 65
DN 50
PN 16

Measuring range 1:80
Impulse transmitter 1x LF
Thermowell 2x input



# We supply you with products for gas flow measurement:



### RMG-GASELAN Regel + Meßtechnik GmbH



Julius-Pintsch-Ring 3, 15517 Fürstenwalde, Germany Telephone (++49) 3361 356-60 • Telefax (++49) 3361 356-836 Internet: www.gaselan.de • e-mail: gaselan@gaselan.de

Gas pressure regulating equipment, displacement meters, complete systems



### RMG Messtechnik GmbH

Otto-Hahn-Straße 5, 35510 Butzbach, Germany
Telephone (++49) 6033 897-0 • Telefax (++49) 6033 897-130
Turbine meters, vortex meters, correctors, flow computers, odorizers

## The other RMG Companies:



### RMG REGEL + MESSTECHNIK GMBH

Osterholzstraße 45, 34123 Kassel, Germany Telephone (++49) 561 5007-0 • Telefax (++49) 561 5007-107 Gas pressure regulators and safety devices



### Bryan Donkin RMG Gas Controls Ltd.

Enterprise Drive, Holmewood, Chesterfield S42 5UZ, England Telephone (++44) 1246 501-501 • Telefax (++44) 1246 501-500 Gas pressure regulating equipment, below ground gas control modules, complete stations



### Bryan Donkin RMG Co. of Canada Ltd.

50 Clarke Street South, Woodstock, Ontario N4S 7Y5, Canada Telephone (++1) 519 5398531 • Telefax (++1) 519 5373339

Domestic gas pressure regulators and safety devices



#### Karl Wieser GmbH

Anzinger Straße 14, D-85560 Ebersberg, Germany Telephone (++49) 8092 2097-0 • Telefax (++49) 8092 2097-10

#### **Beindersheim Plant**

Heinrich-Lanz-Straße 9, 67259 Beindersheim/Pfalz, Germany Telephone (++49) 6233 3762-0 • Telefax (++49) 6233 3762-40 Data logging, monitor systems, danger alarm systems



### WÄGA Wärme-Gastechnik GmbH

Osterholzstraße 45, 34123 Kassel, Germany Telephone (++49) 561 5007-0 • Telefax (++49) 561 5007-207 Gas pressure regulating and metering stations

ETTER Engineering Company is the US Master Distributor 800-444-1962

**Listed Below is Your Local Distributor** 

